

## METOCLEAN SCM-1600

### Professional shoe cover machine for highest demands:

The electric overshoot machine SCM-1600 shrinks a foil over the shoe in a few seconds. The shoe is thus tightly wrapped. Dirt and dirt remain outside. The electric overshoot machine is ideal if you want to quickly and easily equip many visitors with overshoes. Thanks to the simple shrink technology, the SCM-1600 is a very economical way to provide visitors and staff with hygienic foot protection.

- PE film is shrunk around the shoe in 4 seconds
- suitable for every type and size of shoe (also high-heels)
- particularly stable, tear-resistant film for around 1000 shoes
- affordable hygiene solution that pays off quickly
- extremely durable • you save on storage costs for overshoes
- CE certified
- very easy replacement and refilling of the film roll
- electric, for a fixed location
- Weight: 21 kg
- complies with the statutory guidelines

Ideal for use in food processing, productions, industry, laboratories, medical areas

### Product Description

Professional device for very high traffic visitors PE film shrinks around the shoe in just 4 seconds Power operation suitable for every type and size of shoe (even high heels) Tear-resistant film for around 1000 shoes - suitable for dry and not too smooth floors. Favorable hygiene solution that pays off quickly. You save storage costs for overshoes very easy replacement and refilling the film roll electrically, for a fixed location.

### METOCLEAN®

SCM-1600S  
Shoe Cover Machine  
Überschuh-Maschine

for foil rolls  
für Folienrollen



The above statements are based on our present knowledge. Our statements should not be interpreted as a guarantee of characteristics. The use of our products by our customers is subject to different conditions, therefore none of our customers are relieved of the responsibility of testing our products by themselves. A liability for consequential damage will not be accepted in any case. For damage resulting from the use of this information we can only be held responsible if there is evidence of malice or negligence on our part. This data-sheet replaces any previous data sheets.

ASMETEC, METODRILL, METOCHECK, METOLIGHT, METOSTAT, METOCLEAN and METO are registered trade marks of ASMETEC GmbH.  
SCM-1600-DB-E.DOC, VERSION OKT-19

## Installation of SCM-devices

(valid for all versions of series SCM, images may vary)

Unbox device and accessories.

Devices with handle:

Mount carrier tray:

The lower part of the handle is attached to the carrier plate with 4 Allen screws.

Handle must point diagonally forward.

Place SCM in the carrier frame (rollers point backwards into the recess of the carrier plate)

Place the upper handle on the handle carrier

Connect SCM to 230 VAC mains power outlet (Power consumption 1300 Watt max, 75 Watt Standby)

Insert the shrink foil:

Open cover on back side



Insert the film so that the beginning of the roll runs from bottom to top and points forwards to the device



Feed the foil into the device  
(see arrows at the slot)

Press forward button until film  
appears at device front.

Press foot area once.  
Film moves forward., close the  
back cover  
SCM is ready to use

Step with shoe into SCM foil is shrunk at low temperature around the shoe



No risk of burns! The film for the next shoe is automatically advanced.